

WIRING DIAGRAM FOR BASSBARS™



Directions: Tie white/black & green wires together (Ground) and solder to back of volume pot. Take orange wires (hot) and connect to center lug of volume pot. Tape off white ends, or connect to switch for split function (see diagram #14)

Note: All Lead wires should come from the G string side of the pickup.

250K pots recommended for better tone.
C1 = .022mfd cap recommended

