## WIRING DIAGRAM FOR SINGLE-SINGLE-HUM With Splitting Switch



**Directions:** Tie white & green wires together (Ground) and solder to volume pot. Take orange wires (hot) and connect to switch where noted by blue arrows.

**Note:** All Lead wires are on the same side as the high "E" lead string.

