WIRING DIAGRAM FOR LES PAUL®

Directions: Tie white & green wires together (Ground) and solder to volume pot. Take orange wires (hot) and connect to switch where noted by blue arrows.



Note: All Lead wires are on the same side as the high "E" lead string. If leads are up on the side of the bass string then the high "E" drop out! will occur!

