

WIRING DIAGRAM FOR JAZZ BASS®



Directions: Tie white & green wires together (Ground) and solder to volume pot.
Take orange wires (hot) and connect to switch where noted by blue arrows.

Note: All Lead wires are on the same side as the high "E" lead string.

250K pots recommended for better tone.
C1 = .022mfd cap recommended

FOR FOLLOWING BASS PICKUPS
LACE TRANSENSOR
LACE SENSOR

