



# WIRING FOR SERIES/PARALLEL AND PHASING FOR LACE PICKUPS




## STANDARD WIRING FOR SINGLE COIL PHASING



## STANDARD WIRING FOR HUMBUCKER PHASING



## STANDARD WIRING FOR HUMBUCKER SERIES / PARELLEL - OR - SERIES / SPLIT / PARELLEL



## STANDARD WIRING FOR HUMBUCKER SERIES / SPLIT / PHASED WITH ITSELF

